

CONTENTS

preface

USING THIS GUIDE

chapter 1

PRODUCT DESCRIPTION

| | |
|--|------|
| 1.1 Computer Features and Models | 1-1 |
| Models | 1-2 |
| Features | 1-6 |
| 1.2 Intelligent Manageability | 1-8 |
| Accessing the Web Agent | 1-8 |
| Asset Management | 1-8 |
| Fault Management | 1-9 |
| Fault Management Alerts | 1-10 |
| Security Management | 1-10 |
| Configuration Management | 1-11 |
| Managing Power | 1-11 |
| Accessing Power Management | 1-11 |
| Power Management Levels | 1-11 |
| 1.3 Computer External Components | 1-12 |
| 1.4 Design Overview | 1-24 |
| System Board | 1-24 |

chapter 2

TROUBLESHOOTING

| | |
|-------------------------------------|-----|
| 2.1 Preliminary Steps | 2-2 |
| 2.2 Clearing Passwords | 2-2 |
| 2.3 Power-On Self-Test (POST) | 2-4 |
| 2.4 POST Error Messages | 2-4 |

| | | |
|-----|---|------|
| 2.5 | Compaq Utilities..... | 2-9 |
| | Selecting Computer Setup or Compaq Diagnostic for Windows..... | 2-9 |
| | Using Computer Setup | 2-10 |
| | File Menu..... | 2-11 |
| | Security Menu | 2-12 |
| | Advanced Menu | 2-13 |
| | Using Compaq Diagnostics for Windows..... | 2-14 |
| | Factory Default Settings..... | 2-15 |
| 2.6 | Troubleshooting Without Diagnostics | 2-17 |
| | Before Replacing Parts | 2-17 |
| | Obtaining Update Information with Info Messenger | 2-17 |
| | Checklist for Solving Problems..... | 2-18 |

chapter 3

ILLUSTRATED PARTS CATALOG

| | | |
|-----|---|-----|
| 3.1 | Serial Number Location | 3-1 |
| 3.2 | Computer System Major Components..... | 3-2 |
| 3.3 | Miscellaneous Plastics Kit Components | 3-5 |
| 3.4 | Mass Storage Devices..... | 3-6 |
| 3.5 | Miscellaneous | 3-7 |

chapter 4

REMOVAL AND REPLACEMENT PRELIMINARIES

| | | |
|-----|--|-----|
| 4.1 | Tools Required..... | 4-1 |
| 4.2 | Service Considerations..... | 4-2 |
| | Plastic Parts | 4-1 |
| | Cables and Connectors..... | 4-2 |
| 4.3 | Preventing Damage to Removable Drives..... | 4-3 |
| 4.4 | Preventing Electrostatic Damage..... | 4-3 |
| 4.5 | Packaging and Transporting Precautions | 4-4 |
| 4.6 | Workstation Precautions | 4-4 |
| 4.7 | Grounding Equipment and Methods..... | 4-5 |

chapter 5

REMOVAL AND REPLACEMENT PROCEDURES

| | | |
|-----|--|-----|
| 5.1 | Serial Number..... | 5-1 |
| 5.2 | Disassembly Reference Chart..... | 5-2 |
| 5.3 | Preparing the Computer for Disassembly | 5-3 |
| 5.4 | Computer Feet..... | 5-4 |
| 5.5 | Mini PCI Slot | 5-5 |

| | |
|---|------|
| Removing the Mini PCI Slot Cover | 5-5 |
| Installing a Modem or Network Interface Card..... | 5-6 |
| 5.6 Keyboard..... | 5-7 |
| Removing the Keyboard..... | 5-8 |
| 5.7 Memory..... | 5-11 |
| Removing a Memory Expansion Board..... | 5-12 |
| Installing a Memory Expansion Board | 5-13 |
| 5.8 Display | 5-14 |
| Removing the Display | 5-14 |
| 5.9 Real Time Clock (RTC) Battery..... | 5-18 |
| Removing the RTC Battery..... | 5-18 |
| 5.10 LED Board..... | 5-19 |
| Removing the LED Board..... | 5-19 |
| 5.11 Top Cover..... | 5-20 |
| Removing the Top Cover..... | 5-20 |
| 5.12 Front Shield..... | 5-23 |
| Removing the Front Shield | 5-23 |
| 5.13 Diskette Drive (Armada V300 only) | 5-25 |
| Removing the Diskette Drive | 5-25 |
| 5.14 System Board..... | 5-26 |
| Removing the System Board..... | 5-26 |
| 5.15 Voltage Converter Board..... | 5-29 |
| Removing the Voltage Converter Board..... | 5-29 |
| 5.16 Fan..... | 5-31 |
| Removing the Fan..... | 5-31 |
| <i>chapter 6</i> | |
| SPECIFICATIONS | 6-1 |
| <i>appendix a</i> | |
| CONNECTOR PIN ASSIGNMENTS | A-1 |
| <i>appendix b</i> | |
| POWER CORD SET REQUIREMENTS..... | B-1 |

