

INDEX

A

- AC Adapter
 - spare part number, 3-7
 - specifications, 6-10
- air vent
 - illustrated, 1-14
- Asset Management, 1-8
- asset tag number, 1-8
- audio bass port
 - illustrated, 1-12

B

- battery
 - bay
 - illustrated, 1-12
 - light
 - illustrated, 1-12
 - pack
 - 6-cell
 - spare part number, 3-4
 - 9-cell
 - spare part number, 3-4
 - illustrated, 3-2
 - MultiBay
 - spare part number, 3-4
 - specifications, 6-11
 - release latch
 - illustrated, 1-22
 - terminal cable
 - disconnecting, 5-30
- beep codes, 2-8
- boot options, 2-13

C

- cables, 4-2
- caps lock
 - key
 - illustrated, 1-18
 - light
 - illustrated, 1-20

- CD-ROM drive
 - illustrated, 3-2, 3-6
 - space saver
 - illustrated, 3-5
 - spare part number, 3-4, 3-6
 - specifications, 6-7
- combination modem/NIC card
 - installing, 5-6
 - Type II V.90
 - spare part number, 3-4, 5-5
- Compaq
 - utilities, 2-9
- computer
 - components
 - bottom, 1-22
 - keyboard, 1-18, 1-20
 - left side, 1-14
 - rear, 1-16
 - top, 1-12
 - features, 1-6
 - feet, 5-4
 - illustrated, 3-5
 - models, 1-2, 1-4
 - specifications, 6-1
- Computer Setup, 2-9
- Configuration Management, 1-11
- configuration utilities, 2-9
- connector
 - pin assignments, A-1
- connectors, 4-2
- CPU base enclosure
 - illustrated, 3-2
 - spare part number, 3-4
- cursor-control
 - keys
 - illustrated, 1-18

D

- default settings, 2-15
- initialization, 2-15
- power, 2-16
- security, 2-16
- design overview, 1-24

- device
 - options, 2-13
 - security, 2-12
- diagnostics, 2-9
- disassembly
 - preparing the computer, 5-3
 - reference chart, 5-2
- diskette drive, 5-28
 - bezel
 - illustrated, 3-2, 3-5
 - removing, 5-22
 - cable
 - illustrated, 3-6
 - fixed
 - illustrated, 1-12, 3-2
 - spare part number, 3-4, 3-6
 - illustrated, 3-6
 - release latch
 - illustrated, 1-22
 - removable
 - illustrated, 3-2
 - spare part number, 3-4, 3-6
 - removing, 5-28
 - spare part number, 5-28
 - specifications, 6-6
- display
 - release latch
 - illustrated, 1-12
 - removing, 5-16
 - screw cover
 - illustrated, 3-5
 - switch
 - illustrated, 1-18
- display assembly, 5-16
 - 12.1-inch, STN
 - spare part number, 3-3, 5-16
 - specifications, 6-4
 - 12.1-inch, TFT
 - spare part number, 3-3, 5-16
 - specifications, 6-4
 - 13.3-inch
 - spare part number, 3-3, 5-16
 - specifications, 6-3
 - 14.1-inch
 - spare part number, 3-3, 5-16
 - specifications, 6-2
- cables
 - disconnecting, 5-18
 - illustrated, 3-2
- display assembly
 - spare part number, 5-16
- docking
 - connector
 - illustrated, 1-16
 - pinout, A-4
- DualBay
 - illustrated, 1-12
- DVD-ROM drive
 - illustrated, 3-6
 - spare part number, 3-4, 3-6
 - specifications, 6-8

E

- electrostatic
 - preventing damage, 4-3
 - voltage levels, 4-6
- embedded numeric keypad
 - illustrated, 1-18
- external monitor
 - connector
 - illustrated, 1-16

F

- fan, 5-34
 - illustrated, 3-2
 - removing, 5-34
 - spare part number, 3-4, 5-34
- fatal error
 - beep codes, 2-8
 - messages, 2-7
- Fault Management, 1-9
 - alerts, 1-10
- features, 1-6
 - computer, 1-6
- feet
 - installing, 5-4
- Fn keys
 - illustrated, 1-20
- front shield, 5-26
 - illustrated, 3-5
 - removing, 5-26
- function keys
 - illustrated, 1-20

G

- grounding
 - equipment, 4-5
 - methods, 4-5

H

- hard drive
 - 10.0 GB
 - spare part number, 3-6
 - 10.0-GB
 - spare part number, 3-4
 - 12.0 GB
 - spare part number, 3-6
 - 12.0-GB
 - spare part number, 3-4
 - 4.3 GB
 - spare part number, 3-6
 - 4.3-GB
 - spare part number, 3-4
 - 6.0 GB
 - spare part number, 3-6
 - 6.0-GB
 - spare part number, 3-4
- cover
 - illustrated, 1-22, 3-2
 - release latch
 - illustrated, 1-22
 - screw
 - illustrated, 1-22
- illustrated, 3-2, 3-6
- light
 - illustrated, 1-20
- MultiBay adapter
 - spare part number, 3-4
 - specifications, 6-5
- hardware
 - updating, 2-17
- headphone
 - jack
 - illustrated, 1-14
 - pinout, A-2
- heat sink
 - removing, 5-34
- hinge cover
 - illustrated, 3-2, 3-5
 - removing, 5-16

I

- Info Messenger, 2-17
- infrared
 - port
 - illustrated, 1-14

- initialization

- default settings, 2-15

- Intelligent Manageability, 1-8
 - Asset Management, 1-8
 - Configuration Management, 1-11
 - Fault Management, 1-9
 - alerts, 1-10
 - Security Management, 1-10
 - Web Agent, 1-8
- inventory information, 1-9

K

- keyboard
 - connector
 - illustrated, 1-16
 - pinout, A-7
 - removing, 5-10
 - with pointing stick
 - illustrated, 3-2
 - spare part number, 3-3, 5-9
 - without pointing stick
 - illustrated, 3-2
 - spare part number, 3-3, 5-9

L

- LED board, 5-21
 - illustrated, 3-2
 - removing, 5-21
 - spare part number, 3-3, 5-21
- LS-120 SuperDisk drive
 - illustrated, 3-6
 - spare part number, 3-4, 3-6
 - specifications, 6-9

M

- maintenance
 - updating system, 2-17
- maintenance and service guide
 - spare part number, 3-7
- mass storage devices
 - illustrated, 3-6
 - spare part numbers, 3-6

- memory, 5-13
 - expansion board
 - 128 MB
 - spare part number, 3-7, 5-13
 - 256 MB
 - spare part number, 3-7, 5-13
 - 32 MB
 - spare part number, 3-7, 5-13
 - 64 MB
 - spare part number, 3-7, 5-13
 - installing, 5-15
 - removing, 5-14
 - spare part number, 5-13
- messages
 - fatal error, 2-7
 - warning, 2-5
- microphone
 - jack
 - pinout, A-2
- Microsoft
 - logo key
 - illustrated, 1-18
- mini PCI
 - cover
 - illustrated, 3-5
- mini PCI slot, 5-5
 - cover
 - illustrated, 1-22, 3-2
 - removing, 5-5
- miscellaneous
 - spare part numbers, 3-7
- Miscellaneous Plastics Kit
 - components
 - illustrated, 3-2, 3-5
 - spare part number, 3-3, 3-5
- Miscellaneous Screw Kit
 - spare part number, 3-7
- model table, 1-2, 1-4
- models
 - computer, 1-2, 1-4
- modem
 - card
 - illustrated, 3-2
 - Type II V.90
 - spare part number, 3-4
 - installing, 5-6
 - Type II V. 90
 - spare part number, 5-5
- monitor
 - connector
 - pinout, A-7

- mono microphone
 - jack
 - illustrated, 1-14
- mouse
 - connector
 - illustrated, 1-16
 - pinout, A-7
 - keys
 - illustrated, 1-20
- MultiBay
 - illustrated, 1-12
 - light
 - illustrated, 1-20
 - release latch
 - illustrated, 1-22

N

- network interface card
 - illustrated, 3-2
 - installing, 5-6
 - Type II V.90
 - spare part number, 3-4
- NIC
 - installing, 5-6
- NIC card
 - illustrated, 3-2
- num lock
 - key
 - illustrated, 1-20
 - light
 - illustrated, 1-20

P

- packaging
 - precautions, 4-4
- page down
 - key
 - illustrated, 1-18
- page up
 - key
 - illustrated, 1-18
- parallel
 - connector
 - illustrated, 1-16
 - pinout, A-3
- password
 - clearing, 2-3

- PC Card
 - slots
 - illustrated, 1-14
 - space saver
 - illustrated, 3-5
- plastic parts, 4-1
- pointing stick
 - illustrated, 1-20
- POST
 - (Power-On Self-Test), 2-4
 - error messages, 2-4
- power
 - cord
 - set requirements, B-1
 - spare part number, 3-7
 - default settings, 2-16
 - light
 - illustrated, 1-12
 - management, 1-11
 - levels, 1-11
 - switch
 - illustrated, 1-18
- Power-On Self-Test (POST), 2-4
- preparing computer for disassembly, 5-3

Q

- QuickBoot, 2-13

R

- real time clock battery
 - illustrated, 3-2, 3-5
 - removing, 5-20
- removable drives
 - preventing damage, 4-2
- Return Kit
 - spare part number, 3-7
- RJ-11
 - cover
 - illustrated, 3-5
 - jack
 - illustrated, 1-14
- RJ-45
 - cover
 - illustrated, 3-5
 - jack
 - illustrated, 1-14

- RTC battery
 - illustrated, 3-2, 3-5
 - removing, 5-20

S

- scroll lock
 - key
 - illustrated, 1-20
 - light
 - illustrated, 1-20
- security
 - cable slot
 - illustrated, 1-14
 - default settings, 2-16
- Security Management, 1-10
- serial
 - connector
 - illustrated, 1-16
 - pinout, A-1
- serial number, x
 - location, 3-1, 5-1
- service consideration, 4-1
- setup
 - computer, 2-9
- software
 - Info Messenger, 2-17
 - updating, 2-17
- speaker cables
 - removing, 5-24
- specifications
 - AC adapter, 6-10
 - battery pack, 6-11
 - CD-ROM drive, 6-7
 - computer, 6-1
 - diskette drive, 6-6
 - display
 - 12.1-inch, STN, 6-4
 - 12.1-inch, TFT, 6-4
 - 13.3-inch, 6-3
 - 14-1-inch, 6-2
 - DVD-ROM drive, 6-8
 - hard drive, 6-5
 - LS-120 SuperDisk drive, 6-9
 - system DMA, 6-11
 - system I/O address, 6-13
 - system interrupts, 6-12
 - system memory map, 6-15
- static shielding materials, 4-6

- stereo
 - line-in jack
 - pinout, A-2
 - speaker
 - illustrated, 1-20
 - jack
 - pinout, A-2
 - illustrated, 1-14
- suspend
 - button
 - illustrated, 1-18
 - light
 - illustrated, 1-12
- switch cover
 - illustrated, 3-2, 3-5
 - removing, 5-17
- system
 - IDs, 2-12
 - ROM updates, 2-17
- system board, 5-29
 - Celeron 400-MHz processor, 32 MB SDRAM
 - spare part number, 3-4
 - Celeron 400-MHz processor, 64 MB SDRAM
 - spare part number, 3-4
 - Celeron 466-MHz processor
 - spare part number, 3-4
 - illustrated, 3-2
 - Pentium II 366-MHz processor
 - spare part number, 3-4
 - Pentium II 400-MHz processor
 - spare part number, 3-4
 - Pentium III 450-MHz processor
 - spare part number, 3-4
 - removing, 5-29
 - spare part number, 5-29
- system DMA
 - specifications, 6-11
- system I/O addresses
 - specifications, 6-13
- system interrupts
 - specifications, 6-12
- system memory map
 - specifications, 6-15

T

- technician notes, x
- tilt feet
 - illustrated, 1-12
- tools, 4-1

- top cover, 5-22
 - illustrated, 3-2
 - removing, 5-22
 - spare part number, 3-3, 5-22
- touch button
 - removing, 5-7
 - spare part number, 5-7
- touch button with TouchPad
 - spare part number, 5-7
- TouchPad
 - buttons
 - illustrated, 1-18
 - illustrated, 1-18
- transporting
 - precautions, 4-4
- troubleshooting
 - preliminary steps, 2-2
 - without diagnostics, 2-17
- TV
 - connector
 - illustrated, 1-14

U

- universal serial bus
 - connector
 - illustrated, 1-16
- USB
 - connector
 - illustrated, 1-16
- utilities, Compaq, 2-9

V

- voltage converter board, 5-32
 - illustrated, 3-2
 - removing, 5-32
 - spare part number, 3-4, 5-32
- volume control buttons
 - illustrated, 1-12

W

- warning messages, 2-5
- Web Agent, 1-8
- Windows
 - application key
 - illustrated, 1-18
- workstation
 - precautions, 4-4